


## CPR backrest release




The backrest can fall quickly; keep hands clear to avoid injury.




Pull the red CPR handle located on either side of the bed to quickly lower the backrest.


## Brakes and steering



**Brake**  
Brakes applied on all four castors.



**Free**  
All four castors are free to rotate and swivel.




**Steer**  
All four castors can rotate, steering castor cannot swivel.

The brakes should be applied at all times when the bed is stationary.

## Side rails

1




Pull blue release lever to lower the side rail.

2




Make sure the side rail is securely locked when in raised position.



To raise side rail, hold side rail handle and pull side rail up and away from the bed until it locks in the raised position.


## Bed length adjustment (two set positions)

1



Pull the blue extension locking handle (A). Pull out the bed frame (B) to required position and release the handle.


2



Lift the blue extension catch bar (A) and hold the middle of the crossbar (B), then pull the mattress platform to position (C).

## Air mattress length extension

1



Locate the extension flap at the foot end. Lift the flap (A) to access the two sets of connectors (B). Connect the connectors to inflate the extension cushion in the leg section.